
Owner's Guide for the



SVP-1500 Rack Mount Bass Power Amplifier



Made in the
U.S.A.

by





Table of Contents

Important Safeguards and Precautions 2

Introduction 3

Features 3

System Block Diagram 3

The Front Panel 4

The Rear Panel 5

Operation

 Stereo/Bridged Mono/Parallel Mono Modes 6

 Input/Output Connectors 6

Installations

 Stereo 7

 Bridged Mono 7

 Biamp 7

Technical Specifications back cover

Important Safeguards and Precautions






All Ampeg products are designed for continuous safe operation, as long as common sense is used and steps are taken to help avoid certain problems. Abiding by the following rules can help prevent damage to your amplifier, yourself and others.

- The amplifier is equipped with a three-pronged AC power cord. To reduce the risk of electrical shock, **NEVER** remove or otherwise attempt to defeat the ground pin of the power cord.
- Connect the amplifier **ONLY** to a properly grounded AC outlet of the proper voltage for your amp.
- Avoid sudden temperature extremes, rain and moisture. Also, avoid sudden and intense impact. (If the unit has been subjected to any of the preceding abuses, have it looked at by an authorized service center.)
- **NEVER** set the amplifier on a support that might give out under its weight.
- Always keep the total speaker impedance at or above the rated load.
- Unplug the amplifier before cleaning it. **NEVER** spray liquid cleaners onto the amplifier. Wipe it with a slightly dampened, lint-free cloth to remove dirt and film.
- Don't use the amplifier if it has sustained damage to the chassis, controls, or power cord. Refer the unit to an authorized service center for inspection.
- Amplifiers capable of producing high volume levels are also capable of inflicting permanent hearing loss or damage, if the exposure to such levels is prolonged. Such damage is progressive and irreversible!

The chart below shows the U.S. Government Occupational Safety and Health Administration (OSHA) regulations which were in effect at the time of this publication for permissible noise exposure, per 29CFR1910, Table G-16.

SOUND LEVEL dBA SLOW RESPONSE	DURATION PER DAY IN HOURS	SOUND LEVEL dBA SLOW RESPONSE	DURATION PER DAY IN HOURS
90	8	102	1-1/2
92	6	105	1
95	4	110	1/2
97	3	115	1/4 or less
100	2		

According to OSHA, any exposure in excess of those listed above could result in some hearing loss.

 CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN	 ATTENTION RISQUE D'ELECTROCUTION NE PAS OUVRIR	 VORSICHT ELEKTRISCHE SCHLAGEGFAHR NICHT OFFENEN
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.	ATTENTION: POUR REDUIRE D'ELECTROCUTION NE PAS ENLEVER LE COUVERCLE. AUCUNE PIECE INTERNE N'EST REPARABLE PAR L'UTILISATEUR. POUR TOUTE REPARATION, S'ADRESSER A UN TECHNICIEN QUALIFIE.	VORSICHT: ZUR MINIMIERUNG ELEKTRISCHER SCHLAGEGFAHR NICHT DEN DECKEL ABEHMEN. INTERNE TEILE KONNEN NICHT VOM BENUTZER GEWARTET WERDEN. DIE WARTUNG IS QUALIFIZIERTEM WARTUNGSPERSONAL ZU UBERLASSEN.
<p>THIS EQUIPMENT HAS BEEN DESIGNED AND ENGINEERED TO PROVIDE SAFE AND RELIABLE OPERATION. IN ORDER TO PROLONG THE LIFE OF THE UNIT AND PREVENT ACCIDENTAL DAMAGES OR INJURY, PLEASE FOLLOW THESE PRECAUTIONARY GUIDELINES:</p> <p>CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT OPEN CHASSIS; DO NOT DEFEAT OR REMOVE THE GROUND PIN OF THE POWER CORD; CONNECT ONLY TO A PROPERLY GROUNDED AC POWER OUTLET.</p> <p>WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.</p> <p>CAUTION: NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.</p> <p>CAUTION: OUR AMPLIFIERS ARE CAPABLE OF PRODUCING HIGH SOUND PRESSURE LEVELS. CONTINUED EXPOSURE TO HIGH SOUND PRESSURE LEVELS CAN CAUSE PERMANENT HEARING IMPAIRMENT OR LOSS. USER CAUTION IS ADVISED AND EAR PROTECTION IS RECOMMENDED IF UNIT IS OPERATED AT HIGH VOLUME.</p>		
<p>EXPLANATION OF GRAPHICAL SYMBOLS:  = "DANGEROUS VOLTAGE" / "DANGER HAUTE TENSION" / "GEFAHRLICHE SPANNUNG"  = "IT IS NECESSARY FOR THE USER TO REFER TO THE INSTRUCTION MANUAL" / "REFERREZ-VOUS AU MANUAL D'UTILISATION" / "UNBEDINGT IN DER BETRIEBUNGSANLEITUNG NACHSCHLAGEN"</p>		

An Introduction to your new Ampeg SVP-1500 Rack Mount Bass Amplifier

First of all, thank you for choosing one of the finest rack mount bass amplifiers available, the Ampeg SVP-1500. Your new bass amp offers you many outstanding features, such as a rated output of up to 780 watts per channel into 2 ohms, forced fan cooling and a highly-advanced, built-in protection circuit.

In order to achieve the highest performance and longest life from your new bass amp, please read this owner's guide prior to its use.


Features

In true Ampeg tradition, your new SVP-1500 offers you more power, performance and ease of operation than any other bass amp in its class. Below are some of the outstanding features of your new amplifier – features which set it apart from the competition!

- **RUGGED AND PORTABLE:** Ampeg's legendary reliability and three-rack-space design fit into most any audio reinforcement system.
- **BALANCED INPUT JACKS:** Balanced 1/4" phone jacks for use with high or low impedance signals.
- **BUILT-IN LIMITING AND PROTECTION CIRCUITRY:** Automatic protection against clipping, overload conditions, short circuits and overheating.
- **DUAL OUTPUT JACKS:** 1/4" phone and Speakon® jacks for connecting your speakers.


*NOTE: 1/4" jacks not available in some areas.

System Block Diagram





The Front Panel



1: FRONT PANEL EXHAUST VENT:

The SVP-1500 employs a variable-speed internal cooling fan to draw air through the unit to keep it running cool even under extreme operating conditions. The air is drawn in through the unit's rear intake vent (#11) and is forced out through the front panel exhaust vent. This method of cooling draws air out from the interior of the rack and provides more efficient cooling than methods which bring air in from the front and exhaust it through the back. Keep this vent clear and free from obstruction at all times to insure proper cooling.

2: SIGNAL INDICATOR LED: This LED will illuminate when signal is detected at the amplifier's output terminals, providing accurate visual confirmation of signal presence, often helpful in hookup and troubleshooting. The level of the signal must be at about 5% of the amplifier's full rated output to make the LED glow.

3: LIMIT INDICATOR LED: The SVP-1500 employs an internal "Automatic" limit circuit to prevent amplifier "clipping". The Limit LED will illuminate whenever the input signal attempts to overdrive the amplifier's output section, indicating that the Limiter has been called upon to prevent clipping. (Not only does clipping

produce harsh sounding distortion, it is also capable of damaging speaker components - particularly high frequency drivers.) Periodic flashing of the Limit LED indicates operation at or near full output and is no cause for alarm. Steady illumination of the LED indicates constant operation of the Limiter, with the possibility that the input signal should be reduced by means of the Sensitivity control (#13). The Limiter within the SVP-1500 is fully automatic, with no defeat switch, insuring complete protection against clipping at all times.

4: PROTECT INDICATOR LED: This LED will illuminate whenever the internal protection relay on either channel is activated, indicating the possibility of overheating, DC voltage at the outputs, overloads or short circuits. The protection relay is activated for a short period upon initial turn-on and at turn-off to prevent transient "spikes" from being reproduced through your speakers. If the limit and protect indicators for a channel cycle on and off with a signal applied, this indicates the presence of a short circuit or load impedance less than 2 ohms on the output of that channel (less than 4 ohms in the bridged mono mode). In this case, check all wiring for shorts, check the total connected load impedance to be sure it is

not below the amplifier ratings, or check for other potential problems.

5: POWER INDICATOR LED: This LED will illuminate when AC power is applied by means of the Power switch (#7). If the LED fails to illuminate, check the AC outlet or the circuit breaker on the front panel (#6).

6: RESET SWITCH: The SVP-1500 employs an AC line circuit breaker to help protect against damages due to excessive current demands. If the amplifier does not function, check the circuit breaker. If it has opened, the button will be protruding and showing a contrasting color. You may reset it by pressing the button in until it latches. The circuit breaker must cool down for a short time before the button will latch. If the circuit breaker opens repeatedly with no signal input, have the amplifier checked by a qualified service person.

7: POWER SWITCH: This switch turns the amplifier On in the Up position and Off in the down position. When AC power is applied to the amplifier, the Power LED indicator (#5) will illuminate.



Operation

Stereo Mode:

The SVP-1500 can be used in the Stereo Mode as two separate amplifier units, each capable of driving loads down to 2 ohms. Each channel operates independently and has its own input connectors, sensitivity level controls, signal indicator LEDs, automatic limiter, fault protection circuitry, power amp, and speaker outputs. In the Stereo Mode, the Mono/Stereo switch (#14 on the rear panel) must be in the *OUT* position.

Connections to your speakers can be made with either the 1/4" jacks* or the Channel A and B Speakon® jacks (or both since they are wired in parallel). See the illustration labeled "Stereo Operation" on the facing page.

Bridged Mono Mode:

The two power amplifiers can be bridged together to form a single, higher-powered amp. In the Bridged Mono Mode, the amplifier uses Channel A's input jacks and Sensitivity control; Channel B's are disconnected. Channel B's power amp receives its signal from a tap after Channel A's Sensitivity control, but prior to Channel B's Limiter, so each channel is independently protected. To select the Mono Mode, the Mono/Stereo switch (#14 on the rear panel) must be in the *IN* position. Because both channels are being used (bridged in series), the minimum speaker load impedance must be 4 ohms.

Connections to your speakers must be made with the Mono Bridge (middle) Speakon® jack. See the illustration labeled "Bridged Mono Mode Operation" on the facing page.

Biamp Mode:

The SVP-1500 can be used to separately power the lows and highs of a cabinet with biamp inputs or a separate low and high frequency cabinet. For Biamp Operation, the Mono/Stereo switch (#14 on the rear panel) must be in the *OUT* (stereo) position. Connections to your speakers can be made with either the 1/4" jacks* of the Mono Bridge (middle) Speakon® jack. We suggest using Channel A for the low frequencies and Channel B for the highs.

When using a single cabinet with a Speakon® Biamp Input jack, terminate the end of the speaker cable going to the cabinet with a single Speakon® connector. (Wire the connector according to the pinouts on the cabinet's input jackplate label or in its owners manual). If the cabinet has 1/4" Biamp Low and Biamp High Input jacks, or when using separate cabinets for lows and highs, the end of the speaker cable going to the cabinet must be terminated with two 1/4" connectors – one for the highs, one for the lows. (A pigtail connector and/or other adapters may be used to split the low and high speaker wires going to the cabinets.) See the illustration labeled "Stereo Operation" on the facing page.

Input Connectors:

The SVP-1500 uses balanced 1/4" phone jacks as input connectors. These inputs accept High or Low impedance and balanced or unbalanced signals. A "stereo" 1/4" plug (ring/tip/sleeve) must be used to feed a high impedance balanced signal into the amplifier. In the Mono Mode, Channel A's input jack is used; Channel B's input jack is disconnected.

Speaker Output Connectors:

Each channel of the SVP-1500 has both a 1/4" phone jack* and a Speakon® jack. A third Speakon® jack is provided for Mono Bridged use. The Speakon® jacks are more reliable for extended use at high power levels, and their use is always recommended over the 1/4" phone jacks.


On each channel, the Channel A and B Speakon® jacks are wired in parallel with the 1/4" phone jacks: the tip of the 1/4" jack is connected to pin 1+ of the Speakon® jack and the sleeve is connected to pin 1-. Use of both the 1/4" jack and the Speakon® jacks simultaneously to connect two cabinets in parallel is possible, providing proper polarity is observed.

The SVP-1500's Mono Bridge (middle) Speakon® jack is wired as follows: Pins 1+ and 1- = Channel B+ and - respectively; pins 2+ and 2- = Channel A + and - respectively.


**NOTE: 1/4" jacks not available in some areas.*

Installations


Stereo Operation:



Bridged Mono Mode Operation:



Biamp Operation:





Technical Specifications

POWER OUTPUTS (per channel, stereo mode)^{1,2}

	<u>2 ch (20-20kHz)</u>	<u>2 ch 1kHz</u>	<u>2 ch 40Hz (1 cycle)</u>	<u>1 ch 1 kHz</u>	<u>1 ch 40Hz (1 cycle)</u>
8 ohms:	230 watts	260 watts	280 watts	295 watts	300 watts
4 ohms:		425 watts	480 watts	500 watts	550 watts
2 ohms:		560 watts	780 watts	750 watts	900 watts

POWER OUTPUTS (mono mode)^{1,2}

	<u>20-20kHz</u>	<u>1kHz</u>	<u>40Hz (1 cycle)</u>
16 ohms:	460 watts	520 watts	560 watts
8 ohms:		850 watts	960 watts
4 ohms:		1120 watts	1560 watts

FREQUENCY RESPONSE +0, -8dB / 20Hz - 20kHz @ 230 W / channel @ 8 ohms**TOTAL HARMONIC DISTORTION** Less than .25%, 20Hz - 20kHz @230 W / channel @ 8 ohms**SLEW RATE¹** 30 volts / microsecond (stereo mode), 60 volts / microsecond (mono mode)**SIGNAL TO NOISE RATIO^{1,2}** Greater than -100dB from 230 watts / 8 ohms**INPUT TYPE AND IMPEDANCE** Transformerless electronically balanced, 20K actual load impedance. Suitable for Low or High-Z balanced line. One (1) 1/4" phone jack per channel.**INPUT SENSITIVITY** 1.5 V RMS for 230 Watts / 8 ohms**LOAD IMPEDANCE** Stereo Mode: 2 ohms or greater; Bridged Mono Mode: 4 ohms or greater**DAMPING FACTOR¹** Typical 250 (1kHz, 8 ohms)**OUTPUT CONNECTIONS** 1/4" phone jack*, plus Speakon® jacks each channel; Speakon® jack for Mono Bridge/Biamp**PROTECTION CIRCUITRY** Short circuit, RF burnout, overtemp, turn on/off transient and DC protection, Speaker protection relays, built-in auto limiter (Anti-clip)**COOLING** Forced air fan cooling, rear intake, front exhaust**POWER REQUIREMENTS**
115VAC 60Hz, 880VA
100/110VAC 50/60Hz, 880VA
230VAC, 50/60Hz, 880VA**CIRCUIT BREAKER** 10 amp (mains)**SIZE AND WEIGHT** 19" W x 5.25" H x 12.5" D; 33 lbs. 483mm x 133mm x 317mm; 15Kg.¹typical performance ²@115 VAC 60Hz

*NOTE: 1/4" jacks not available in some areas.

Ampeg reserves the right to change specifications without notice.