



Ampeg Master Fuse List

All Values are for US 120VAC

Current Products

Model	Fuse Value
Heritage 50th Anniversary SVT	F1 (Mains)- 10A / 250V Slow Blow F2- 1.6A / 250V Slow Blow
Heritage SVT-CL	F1 (Mains)- 10A / 250V Slow Blow F2- 1.6A / 250V Slow Blow
Classic SVT-CL	F1 (Mains)- 10A / 250V Slow Blow F2- 1.6A / 250V Slow Blow
Classic V-4B	F1 (Mains)- 4A / 250V Slow Blow F2 (Bias VAC)- 32mA / 250V Slow Blow F3 (Control/Bias VAC)- 125mA / 250V Slow Blow F4 (Control/Bias VAC)- 125mA / 250V Slow Blow F5 (Filament VAC)- 8A / 250V Slow Blow F6 (Secondary)- 1.25A / 250V Slow Blow
Micro VR	F1 (Mains)- 4A / 250V Slow Blow
Micro CL	F1 (Mains)- 3A / 250V
PF-350	F1 (Mains)- 6.3A / 250V Slow Blow
PF-500	F1 (Mains)- 10A / 250V Slow Blow
PF-800	F1 (Mains)- 10A / 250V Slow Blow
PF-20T	F1 (Mains)- 2A / 250V Slow Blow F2 (Secondary)- 250mA / 250V Slow Blow F3 (Heater)- 5A / 250V Slow Blow
PF-50T	F1 (Mains)- 2A / 250V Slow Blow F2 (Secondary)- 500mA / 250V Slow Blow F3 (Heater)- 5A / 250V Slow Blow F4 (Bias Ground)- 500mA / 250V Slow Blow
Venture V3	Refer to the ICEpower 300 ASI datasheet
Venture V7	Refer to the ICEpower 700 ASI datasheet
Venture VI2	Refer to the ICEpower I200 ASI datasheet
SVT-3Pro	Mains- 10A / 250V Slow Blow F2 (Secondary)- 125mA / 250V Slow Blow

YAMAHA GUITAR GROUP INC.

YGG Service Department

26580 Agoura Rd. • Calabasas, CA • 91302 • USA

Customer Support Phone: 818.575.3600

Service Inquiries Email: service@yamahaguitargroup.comwww.ampeg.com



Model	Fuse Value
SVT-4Pro	Mains- Circuit Breaker 15A Push to Reset F1 (Secondary)- 1.6A / 250V Slow Blow F2 (Secondary)- 1.6A / 250V Slow Blow F3 (Voltage Multiplier)- 125mA / 250V Slow Blow
SVT-7Pro	Mains- 10A
RB-108	Mains- 1A / 250V Slow Blow
RB-110	Mains- 1.25A / 250V Slow Blow
RB-112	Mains- 3.15A / 250V Slow Blow
RB-115	Mains- 3.15A / 250V Slow Blow
RB-210	Mains- 8A / 250V Slow Blow

Discontinued Products

Model	Fuse Value
Classic SVT-VR	F1 (Mains)- 10A / 250V Slow Blow F2- 1.6A / 250V Slow Blow
Classic SVT-AV	F1 (Mains)- 10A / 250V Slow Blow F2- 1.6A / 250V Slow Blow
Heritage B-15	F1 (Mains) 3.15A / 250V Slow Blow F2 (Secondary) 500mA / 250V Slow Blow
Heritage B-15N	F1 (Mains) 4A / 250V Slow Blow F2 (Secondary 5VAC) 6.3A / 250V Slow Blow F3 (Secondary 360VAC) 1A / 250V Slow Blow F4 (Secondary 360VAC) 1A / 250V Slow Blow F5 (Secondary 6.3VAC) 8A / 250V Slow Blow
Heritage R-12R	Mains- 2A / 250V Slow Blow
BA-108v2	Mains- 630mA / 250V Slow Blow
BA-110v2	Mains- 1.25mA / 250V Slow Blow
BA-112v2	Mains- 3.15A / 250V Slow Blow
BA-115v2	F1 (Mains) 4A / 250V Slow Blow
BA-210v2	F1 (Mains) 6.3A / 250V Slow Blow



Model	Fuse Value
SVT-2Pro	F1 (Mains)- 10A / 250V Slow Blow F2- 1.6A / 250V Slow Blow
SVT-5Pro	Mains- Circuit Breaker 15A Push to Reset F1 (Secondary)- 1.6A / 250V Slow Blow F2 (Secondary)- 1.6A / 250V Slow Blow F3 (Voltage Multiplier)- 125mA / 250V Slow Blow
SVT-6Pro	Mains- Circuit Breaker 15A F1 (Secondary)- .125A / 250V Slow Blow
SVT-8Pro	Mains- Circuit Breaker 15A
BIRE	Mains- 6.25A / 250V Slow Blow
B2RE	Mains- 10A / 250V Slow Blow
B4R	Mains- Circuit Breaker 8A F1 (Secondary)- 1A / 250V Slow Blow F2 (Secondary)- 1A / 250V Slow Blow F3 (Secondary)- 1.5A / 250V Slow Blow F4 (Secondary)- 1.5A / 250V Slow Blow
B5R	Mains- Circuit Breaker 15A F1 (Secondary)- 1.5A / 250V Slow Blow F2 (Secondary)- 1.5A / 250V Slow Blow F3 (Secondary)- 1A / 250V Slow Blow F4 (Secondary)- 1A / 250V Slow Blow
B-50R	F1 (Mains)- 2A / 250V Slow Blow
B-100R	F1 (Mains)- 2.5A / 250V Normal Blow
B-200R	F1 (Mains)- 4A / 250V Slow Blow
B500DR	Mains- Circuit Breaker 8A F1 (Secondary)- .6A / 250V Slow Blow F2 (Secondary)- .6A / 250V Slow Blow F3 (Secondary)- 1A / 250V Slow Blow F4 (Secondary)- 1A / 250V Slow Blow
BA-108	Mains- 800mA / 250V Slow Blow
BA-1110	Mains- 1.6A / 250V Slow Blow
BA-112	F1 (Mains)- 2A / 250V Slow Blow
BA-115	F1 (Mains)- 2.5A / 250V Slow Blow
BA-210	F1 (Mains)- 4A / 250V Slow Blow

YAMAHA GUITAR GROUP INC.

YGG Service Department

26580 Agoura Rd. • Calabasas, CA • 91302 • USA

Customer Support Phone: 818.575.3600

Service Inquiries Email: service@yamahaguitargroup.com



Model	Fuse Value
BA-II5HP	F1 (Mains)- 4A / 250V Slow Blow
BA-II5HPT	F1 (Mains)- 4A / 250V Slow Blow
BA-II5SP	F1 (Mains)- 2.5A / 250V Slow Blow
BA-2IOSP	F1 (Mains)- 4A / 250V Slow Blow
BA-II5T	F1 (Mains)- 25A / 250V Slow Blow
BA-300	F1 (Mains)- 4A / 250V Slow Blow
BA-500	Mains- 10A / 250V Slow Blow
SVT-I50H	F1 (Mains)- 5A / 250V Slow Blow
SVT-GS	Mains- 10A / 250V Slow Blow
SVT-350H	Mains- 10A / 250V Slow Blow
SVT-450H	Mains- 10A / 250V Slow Blow
GVT5-II0	Mains- 2A / 250V Slow Blow F1 (Secondary)- .125A / 250V Slow Blow F2 (Secondary)- .125A / 250V Slow Blow F3 (Secondary)- 4A / 250V Slow Blow
GVT5H	Mains- 2A / 250V Slow Blow F1 (Secondary)- .125A / 250V Slow Blow F2 (Secondary)- .125A / 250V Slow Blow F3 (Secondary)- 4A / 250V Slow Blow
GVTI5-II2	Mains- 2A / 250V Slow Blow F1 (Secondary)- 4A / 250V Slow Blow F2 (Secondary)- .5A / 250V Slow Blow F3 (Secondary)- .5A / 250V Slow Blow F4 (Secondary)- 4A / 250V Slow Blow
GVTI5H	Mains- 2A / 250V Slow Blow F1 (Secondary)- 4A / 250V Slow Blow F2 (Secondary)- .5A / 250V Slow Blow F3 (Secondary)- .5A / 250V Slow Blow F4 (Secondary)- 4A / 250V Slow Blow
GVT52-II2	Mains- 4A / 250V Slow Blow F1 (Secondary)- 3.15A / 250V Slow Blow F2 (Secondary)- 3.15A / 250V Slow Blow F3 (Secondary)- 8A / 250V Slow Blow F4 (Secondary)- 1A / 250V Slow Blow

YAMAHA GUITAR GROUP INC.

YGG Service Department

26580 Agoura Rd. • Calabasas, CA • 91302 • USA

Customer Support Phone: 818.575.3600

Service Inquiries Email: service@yamahaguitargroup.com



Model	Fuse Value
GVT52-212	Mains- 4A / 250V Slow Blow F1 (Secondary)- 3.15A / 250V Slow Blow F2 (Secondary)- 3.15A / 250V Slow Blow F3 (Secondary)- 8A / 250V Slow Blow F4 (Secondary)- 1A / 250V Slow Blow
PB-250 (SLM)	Mains- Circuit Breaker 4A F1 (Secondary)- 10A / 250V Slow Blow
PB-800 (SLM)	Mains- Circuit Breaker 10A
PBC228 (SLM)	Mains- Circuit Breaker 4A
PBC2112/2210 (SLM)	Mains- Circuit Breaker 4A
R-12R (SLM)	Mains- 2A / 250V Slow Blow
R-212R(SLM)	Mains- 2A / 250V Slow Blow

YAMAHA GUITAR GROUP INC.

YGG Service Department

26580 Agoura Rd. • Calabasas, CA • 91302 • USA

Customer Support Phone: 818.575.3600

Service Inquiries Email: service@yamahaguitargroup.com