



MODEL NO. M-18
SERIAL

Tube Location (from left to right)
V1 6SL7 V2 6SL7 V3 6SL7 V4 6L6 V5 6L6 V6 5U4

CONNECTED TO THE
AUTO-TRANSFORMER
FOR 240V

